

V-Cone Flow Meter Flow Formulas

Insertion Device # 15

Base Formula : $Q_{\text{gpm}} = 5.6748766 D^2 \beta^2 C_d (\Delta P)^{1/2} / (1-\beta^4)^{1/2}$

Component	Meter I.D. (D)	Beta Ratio (β)	Discharge Coeff (Cd)	Formula
BPM1-F	0.438"	0.532	0.8290	$Q_{\text{gpm}} = 0.26633(\Delta P)^{1/2}$
FM1-F	0.656"	0.701	0.8049	$Q_{\text{gpm}} = 1.10906(\Delta P)^{1/2}$
PS1-F	0.656"	0.701	0.8061	$Q_{\text{gpm}} = 1.11071(\Delta P)^{1/2}$
BPM2-F	0.438"	0.532	0.8076	$Q_{\text{gpm}} = 0.25945(\Delta P)^{1/2}$
FM2-F	0.656"	0.769	0.7846	$Q_{\text{gpm}} = 1.40511(\Delta P)^{1/2}$
PS2-F	0.656"	0.701	0.8119	$Q_{\text{gpm}} = 1.11871(\Delta P)^{1/2}$