

V-Cone Flow Meter Flow Formulas

Insertion Device # 8

Base Formula : $Q_{\text{gpm}} = 5.6748766 D^2 \beta^2 C_d (\Delta P)^{1/2} / (1-\beta^4)^{1/2}$

Component	Meter I.D. (D)	Beta Ratio (β)	Discharge Coeff (C_d)	Formula
BPM1-F	0.438	0.532	0.8187	$Q_{\text{gpm}} = 0.26302(\Delta P)^{1/2}$
FM1-F	0.656	0.769	0.7712	$Q_{\text{gpm}} = 1.38111(\Delta P)^{1/2}$
PS1-F	0.656	0.701	0.8077	$Q_{\text{gpm}} = 1.11292(\Delta P)^{1/2}$
BPM2-F	0.438"	0.532	0.8267	$Q_{\text{gpm}} = 0.26559(\Delta P)^{1/2}$
FM2-F	0.656"	0.769	0.7867	$Q_{\text{gpm}} = 1.40887(\Delta P)^{1/2}$
PS2-F	0.656"	0.701	0.7964	$Q_{\text{gpm}} = 1.09735(\Delta P)^{1/2}$