# DESIGN OF THE JEFFERSON LAB IR UPGRADE FEL OPTICAL CAVITY

Michelle D. Shinn, G. R. Baker, C. P. Behre, S. V.Benson,M. E. Bevins, L.A. Dillon-Townes, H. F. Dylla, E. J. Feldl,J. F. Gubeli, R. D. Lassiter, F. D. Martin, and G. R. Neil

Work supported by the Office of Naval Research, the Joint Technology Office, the Commonwealth of Virginia, the Air Force Research Laboratory, and by DOE Contract DE-AC05-84ER40150



### - OUTLINE

- Introduction to the JLab IR Upgrade FEL
- Design challenges
- Hardware
- Conclusions





Operated by the Southeastern Universities Research Association for the U.S. Dept. of Energy

#### - DESIGN CHALLENGES -

- Design must provide cooling to offset power loading in a high vacuum environment
  - Estimated absorbed power is 10 50W
- Must develop method for deforming HR that are amenable to high vacuum environment.
- Must provide mirror actuation (coarse and fine) amenable to high vacuum environment.
- Design must not expose optics to irradiances that damage them.



Optical Cavity for 10 kW is based on IR Demo 1/2

#### •Transmissive outcoupler on near-concentric cavity

#### • Add ROC control on total reflector

Parameter	IR Demo	IR Upgrade
Cavity length (m)	8.0105	32.042
Rayleigh range (m)	0.4	2.0
Cavity	101	65
magnification		
Angular tolerance	4.5	1.8
at 3 µm (µrad)		
Mirror ROC (m)	4.0451	16.271



#### THE UPGRADE OPTICAL CAVITY -

- Like the IR Demo optical cavity:
  - We will use a near-concentric resonator
  - The cavity mirrors will be in a high-vacuum environment
  - Require remote control and monitoring of mirror position and relative cavity length.
- Unlike the IR Demo optical cavity:
  - We will switch mirrors having different reflectivities in vacuo
  - We will deform the high reflector to compensate for thermally-induced changes in the radius of curvature.
  - We will incorporate active mirror orientation control and monitoring.
    - Designed for cryogenic cooling of the outcoupler mirror.
  - Our philosophy is to incorporate elements required for future upgrades now, so we save time and cost later.

Operated by the Southeastern Universities Research Association for the U.S. Dept. of Energy

lefferson Vab



# HR OPTICAL CAVITY UNDERGOING TESTS

Metal-coated mirror (3-14 µm)

Dielectric mirror  $\lambda > 9 \ \mu m$ 

Dielectric mirror  $4 > \lambda > 9 \ \mu m$ 

Dielectric mirror  $\lambda < 4 \ \mu m$ 

efferson Pab



## MIRROR FIGURE CONTROL

- To achieve the correct ROC of 16.271 m, we procure mirrors made from silicon substrates with ROC ~ 17 m, then bend them to the correct ROC.
  - This reduces the cost associated with producing an optic with a precise ROC.
- Review of designs amenable to high vacuum environment suffer from nonspherical errors.
- Our design:\*
  - Simultaneously obtain backplane cooling.
  - Produces a spherical mirror figure, keeping the Rayleigh range constant as well as correcting a major component of the total aberration.
- Design was modeled and preliminary design produced under contract to Advanced Energy Systems.
  - \* Patent application filed

Operated by the Southeastern Universities Research Association for the U.S. Dept. of Energy

[efferson Vab



## - DISCUSSION

- For 10 kW output and ~ 15% outcoupling, the circulating power in the cavity is ~ 70 kW.
- If the mirror absorption is 100 ppm, the absorbed power is 7 W.
  - We anticipate obtaining lower loss coatings.
- We loaded our test mirror to 32 W absorbed power, and had  $\sim 0.1\lambda$  P-V distortion of the reflected wavefront.
  - Our spec is  $< 0.2\lambda$ , so we have a comfortable margin.
- Our ability to maintain the ROC by adding feedback should be quite straightforward.



#### – ULTRAVIEWER –

Exceeds angular repeatability spec of 50 µrad





# ALIGNMENT AND ROC CONTROL SUBSYSTEM

- Cold alignment (no lasing) will be done with external HeNe lasers, properly expanded and collimated, beam introduced with insertable mirrors (the ultraviewers), as was done on the IR Demo.
  - Beam size and position checked at wiggler.
    - This allows us to set the initial ROC as well.
- The Optical Cavity Mirror Metrology System (OCMMS) monitors the relative change in ROC and actively controls the mirror orientation.
  - External HeNe lasers reflected from mirrors positioned on either end of wiggler, and in the vacuum system.
  - Beams reflect off cavity mirror, then back outside the vacuum chamber, where it falls on a CCD camera.
  - Piezos on the mirror mount are used to maintain alignment.
- Use Foucault technique to measure the ROC.

Operated by the Southeastern Universities Research Association for the U.S. Dept. of Energy

(efferson Pab



### – OCMMS HARDWARE ——

- Cross contains input/output viewports for sampling laser.
- In-vacuum mirror mount made of Invar and gold-plated to reduce thermallyinduced distortion.







## — CONCLUSIONS

- Our design for the upgrade optical cavity is based on sound design principles:
  - From the synchrotron light source community
  - Other facilities with considerable optics expertise, *i.e.* LLNL
  - Other FEL facilities
  - Best-practice by optics companies
- Our design incorporates lessons learned from operating the IR Demo for 3.5 years.
- Our design provides flexibility for upgrades in power and wavelength range.

